

Airport Signs - Action and Purpose

15-33	TWY/RWY HOLD POSITION: Hold Short of Runway on Taxiway		VFR HOLD POSITION BOUNDARY: Exit Boundary of Rwy Protected Area
ALSO...	RWY/RWY HOLD POSITION: Hold Short of Intersecting Runway		INSTRUMENT AREA BOUNDARY: Instrument Hold Position
15-APCH	RWY APCH HOLD POSITION: Hold Short of Acft on Approach		TWY DIRECTION: Defines Direction & Designation of Intersecting Taxiway(s)
INST	INST HOLD POSITION: Hold Short of INST Critical Area		RWY EXIT: Defines Direction & Designation of Exit Twy from Rwy
	NO ENTRY: Identifies Paved Areas Where Aircraft Entry is Prohibited		OUTBOUND DESTINATION: Defines Direction to Take-Off Runways
	TAXIWAY LOCATION: Identifies Twy on Which Vehicle/Aircraft is Located		INBOUND DESTINATION: Defines Direction for Arriving Aircraft
	RUNWAY LOCATION: Identifies Rwy on Which Vehicle/Aircraft is Located		

TOWER FREQUENCY

Reference: AFI 11-218 Aircraft Operations and Movement on the Ground

ATCT LIGHT GUN SIGNALS

	STEADY GREEN → Cleared to cross, Proceed or Go
	FLASHING GREEN → Not Applicable
	STEADY RED → STOP
	FLASHING RED → Clear the Taxiway/Runway
	FLASHING WHITE → Return to Starting Point on Airport
	ALTERNATING RED/GREEN → Exercise Extreme Caution
	15-33 VFR Hold Position
	INST INST Critical Area Markings

Airport Markings

	VFR HOLD POSITION: Hold Short of Rwy
	ALTERNATE RUNWAY HOLD POSITION: Hold Short of Rwy
	INSTRUMENT HOLD POSITION: Hold Short During IMC Conditions
	TAXIWAY/TAXIWAY HOLDING POSITION: Hold Short of Intersecting Taxiway When Directed by ATC
	TAXIWAY EDGE: Defines Edge of Usable Full Strength Taxiway Pavement. Adjoining Pavement NOT Usable
	DASHED TAXIWAY EDGE: Defines Edge of Taxiway Where Adjoining Pavement or Apron IS Available for Taxi

GROUND FREQUENCY

AFVA 11-240 USAF Airport Signs and Markings

AFVA 11-240, 2 June 2004
Prescribed by AFI 11-218
OPR: HQ AFFSA/XOF
USAF Airport Signs and Markings
Distribution: F